

**System service parts for ThinkStation E32
(Tower Form Factor)**

Machine type : 30A0, 30A1

Part No.	CRU ID	Description
PLANARS		
03T6749	N	Intel C226 ATX planar for W7
03T6750	N	Intel C226 ATX planar for W8P
03T6751	N	Intel C226 ATX planar for W8S
CPU		
03T7163	2	Intel Core i5-4670 84W
03T7164	2	Intel Core i5-4570 84W
03T7166	2	Intel Core i7-4770 84W
03T6754	2	Intel E3-1280V3 82W
03T6755	2	Intel E3-1270V3 80W
03T6756	2	Intel E3-1240V3 80W
03T6757	2	Intel E3-1230V3 80W
03T6758	2	Intel E3-1220V3 80W
03T6759	2	Intel E3-1275V3 84W
03T6760	2	Intel E3-1245V3 84W
03T6761	2	Intel E3-1225V3 84W
03T7827	2	Intel Ci3 Haswell 2C i3-4340 3.6G
03T7828	2	Intel Ci3 Haswell 2C i3-4330 3.5G
03T7829	2	Intel Ci3 Haswell 2C i3-4130 3.4G
03T7830	2	Intel PDC Haswell 2C G3430 3.3G
03T7831	2	Intel PDC Haswell 2C G3420 3.2G
03T7832	2	Intel PDC Haswell 2C G3220 3.0G
MEMORY		
03T7218	1	4GB 1600MHz DDR3 UDIMM PC3-12800
03T7219	1	8GB 1600MHz UDIMM DDR3 PC3-12800
03T7220	1	2GB 1600MHz UDIMM DDR3 PC3-12800
03T8260	2	2GB PC3-12800E 1600MHz D
03T8261	2	4GB PC3-12800E 1600MHz D
03T8262	2	8GB PC3-12800E 1600MHz D
HARD DISK DRIVES		
03X3795	1	Seagate Muskie+ 3.5 SATA 6G 7.2K RPM 2000G/p
45K0627	1	DT HDD 250GB
45K0629	1	DT HDD 500GB
04X2603	1	Toshiba 512G SSD
04X2608	1	Toshiba 512G SSD
04X2602	1	Toshiba 256G SSD
04X2604	1	Toshiba 128G SSD
04X2601	1	Toshiba 128G SSD
04X2606	1	Toshiba 128G SSD
04X2607	1	Toshiba 256G SSD
04X2605	1	Toshiba 256G SSD
03T6771	1	SSD 480GB 2.5
03T6770	1	SSD 240GB 2.5
03T6769	1	SSD 180GB 2.5
03T6772	1	SSD 24GB Samsung CM851

04X4426	1	Lenovo SSD mSATA Cache use only SSD 24GB Samsung mSATA CM851-24
03X4431		3.5inch 7200RPM SATA6G 3TB HDD
OPTICALS		
45K0487	1	recordable drive
45K0489	1	Slim BD Rambo WithBezel
71Y5543	1	DVD-ROM Drive 16x/48x SATA
71Y5545	1	DVD Record
DVD RAM		
71Y5848	N	Slim SATA
45K0433	N	Tray Rambo
ADAPTERS		
03T8162	N	PCI-e x1 1000M ASF NIC FH(R)
03T8163	N	PCI-e x1 1000M ASF NIC LP(R)
03T8165	N	MiniPCIE to PCIE riser card FH
03T8166	N	Dual band dipole antenna
03T8168	N	MiniPCIE to PCIE riser card LP
03T9929	N	Universal Adapter Bracket
60Y3253	N	TP 22 WLAN
89Y1712	N	- PCIE 13
03T8419	N	IEEE 1394a (Firewire-400) PC
03T8424	N	Intel 82574L Gigabit CT2 Desktop Ethernet Adapter
GRAPHIC CARDS		
03T8308	N	NVIDIA NVS510(Mini DPx4) - 2GB DDR3
03T8309	N	Nvidia Quadro 610 (Dual link DVI+DP) - 1GB GDDR3
03T8310	N	Nvidia Quadro 2100 (Dual link DVI x 2+Mini DP) - 2GB GDDR5
03T8312	N	NVIDIA Quadro 4100 (Dual link DVI+DP+DP) - 3GB GDDR5
03T6752	N	NVS315 ATX-1GB GDDR3
03T6753	N	NVS315 LP-1GB GDDR3
03T8821	N	AMD FirePro 2270 (DMS-59 to DVI dongle) 512M GDDR3
03X3640	N	Intel® 1Gbps Gigabit ET Dual Port Server Adapter
03T8822	N	AMD FirePro 2460 Multi-View (DP x 4) 512M GDDR3
03T8823	N	AMD FirePro V3900 (DVI, DP) 1GB DDR3
04X2177	N	VGA CAP-COMMON
03T8824	N	AMD FirePro V4900 (DVI, DP, DP) 1GB GDDR5
03X4376	N	I340 Quad Port
03T8760	N	Intel EthernetI350-T4
03T8610	N	1394 PCIE LP
46R1519	N	Parallel Card -SFF
71Y5498	N	Parallel card HP
BEZELS		
03T9916	N	ODD/FDD cover, retainer
30X3755	N	ODD Blank Bezel
04X2347	N	Non ODD/2nd HD bezel W/O Cardreader
04X2346	N	Non ODD/2nd HD bezel W Cardreader
04X2344	N	ODD bezel with Cardreader
04X2348	N	Slim ODD bezel w/O Cardreader
04X2345	N	ODD bezel without Cardreader
Cables		
03T6632	N	DP to 2DP Hub
03T6634	N	SMA to Ipex Cable
03T8177	N	Second Serial Port Cable

03T9593	N	Cable lock
41R3308	N	eSATA Cable
41R3311	N	eSATA Cable
43N9091	N	Speaker Cable
43N9134	N	SATA Cable
43N9134	N	SATA Cable
43N9462	N	Cable clip FW-6D
45J9495	N	ThrmI Sense Cable
45J9596	N	FRUpower Cable
54Y8252	N	Speaker Cable
54Y8255	N	Cable DVI_Adapter
54Y8286	N	SATA power Cable(200mm_180mm_180mm)
54Y8415	N	Cable,250mm SATA Cable 30awg_ w_o latch_R angle
54Y9339	N	Cable,SATA power Cable(200mm_200mm)
54Y9340	N	Cable,SATA power Cable(400mm)
54Y9341	N	Cable SATA power Cable(200mm)
54Y9356	N	Cable, ,Antenna,550mm, 25L
54Y9377	N	Cable,460mm SATA Cable 2 latch , right angle
54Y9378	N	Cable SATA power Cable(380mm_50mm)
54Y9385	N	Cable,USB 3.0 F_IO_A500mm_U380mm_LED500mm
54Y9916	N	Cable, LED/Switch Cable (11L_420MM)
54Y9922	N	sens Cable
54Y9948	N	SATA Cable
71Y6221	N	Cable300mm
54Y9360	N	Cable,50mm 1 to 2 fan power converter Cable
54Y9399	N	Cable, 178mm DP to Slim VGA dongle
54Y9395	N	Cable,300mm SATA Cable 1 latch , right angle
54Y9375	N	Cable,USB 3.0 F_IO_A500mm_U280mm_angle
43N9149	N	PS2 Cable
CARDREADERS		
03T7115	2	Media Card Reader TW
45K6378	2	Retainer
POWER SUPPLY		
54Y8897	2	TFX240W 85% Single PSU
54Y8899	2	ATX450W 92% Single PSU
54Y8900	2	ATX280W 85% Single PSU
54Y8872	2	240W PSU
MECHANICALS		
03T8318	N	Mini Display Port to HD
03T8319	N	Mini Display Port
03T8320	N	Mini Display Port to DVI
03T8400	N	DP to DVI Dongle
03T8401	N	DP to DVI Dongle
03T8402	N	DMS59 to Dual DVI
03T8403	N	DMS59 to Dual DP Dongle
03T8404	N	DP to HDMI Dongle
03T9723	N	8025 front system fan
03T9724	N	8025 Front System fan
03T9735	N	card reader bracket Assembly
03T9738	N	mSata board bracket
03T9876	N	mSata board bracket

41A5041	1	Arabic/Fre 462
41A5042	1	Bel/Fren 120
41A5043	1	Bel/UK 120
41A5044	1	Brazil/Port275
41A5045	1	Bulgarian 442
41A5046	1	CHN/US 467
41A5047	1	Czech(ABB)243
41A5048	1	Danish 159
41A5049	1	Dutch 143
41A5050	1	French 189
41A5051	1	Fren Cana445
41A5052	1	Fren Can 58
41A5053	1	German129
41A5054	1	Greek 319
41A5055	1	Hebrew 212
41A5056	1	Hungarian 208
41A5057	1	Iceland 197
41A5058	1	Italian 142
41A5059	1	JPN 194
41A5060	1	Korean 413
41A5061	1	LA Spanish 171
41A5062	1	Norwegian 155
41A5063	1	Polish 214
41A5064	1	Portugese 163
41A5065	1	Romanian 096
41A5066	1	Russian/Cyr441
41A5067	1	Serbian/Cyr118
41A5068	1	Slovak 153
41A5069	1	Spanish 172
41A5070	1	Swd/Finn 153
41A5071	1	Swiss, F/G 150
41A5072	1	Thailand 191
41A5073	1	Turkish 440
41A5074	1	Turkish 179
41A5075	1	UK ENG 166
41A5076	1	US Euro 103P
41A5077	1	Slovenian+++
41A5080	1	Greek/US
41A5289	1	US English103P
41A5290	1	Arabic 253
41A5291	1	Arabic/Fren462
41A5292	1	Belgium/Fr 120
41A5293	1	Belgium/UK 120
41A5294	1	Brazil/Port275
41A5295	1	Bulgarian 442
41A5296	1	Chinese/US 467
41A5297	1	Czech(QWRT)489
41A5298	1	Danish 159
41A5299	1	Dutch 143
41A5300	1	French 189
41A5301	1	Canada/Fr 445
41A5302	1	Canada/Fr 058

41A5303	1	German 129
41A5304	1	Greek 319
41A5305	1	GREEK/US 359
41A5306	1	Hebrew 212
41A5307	1	Hungarian 208
41A5308	1	Iceland 197
41A5309	1	Italian 141
41A5310	1	Japanese 194
41A5311	1	Korean 413
41A5312	1	LA Spanish 171
41A5313	1	Norwegian 155
41A5314	1	Polish 214
41A5315	1	Portuguese 163
41A5317	1	Romanian 096
41A5318	1	Russian/Cyr441
41A5319	1	Serbian/Cyr118
41A5320	1	Slovakian 245
41A5321	1	Spanish 172
41A5322	1	Swedish/Fin153
41A5323	1	Swiss, F/G 150
41A5324	1	Thailand 191
41A5325	1	Turkish 440
41A5326	1	Turkish 179
41A5327	1	UK English 166
41A5328	1	US Euro 103P
41A5329	1	Slovenian 234
45J4880	1	Arabic 470
45J4896	1	Lithuanian 494
51J0059	1	Estonia454 105
54Y8380	1	Lenovo Slim New F5 USB Keyboard
54Y8381	1	Preferred Pro USB Keyboard
54Y8382	1	Preferred Pro PS2 Keyboard Indian
54Y9293	1	Slim New F5 USB US103P
54Y9294	1	Slim New F5 USB Arabic 253
54Y9295	1	Slim New F5 USB Arabic/French462
54Y9296	1	Slim New F5 USB Belgium/French 120
54Y9297	1	Slim New F5 USB Belgium/UK 120
54Y9298	1	Slim New F5 USB Brazil/Portuguese275
54Y9299	1	Slim New F5 USB Bulgarian 442
54Y9300	1	Slim New F5 USB Traditional Chinese467
54Y9301	1	Slim New F5 USB Czech (QWERTY or ABB)489
54Y9302	1	Slim New F5 USB Danish 159
54Y9303	1	Slim New F5 USB Dutch 143
54Y9304	1	Slim New F5 USB French 189
54Y9305	1	Slim New F5 USB French Canadian 445
54Y9306	1	Slim New F5 USB French Canadian(Bilingual)58
54Y9307	1	Slim New F5 USB German 129
54Y9308	1	Slim New F5 USB Greek 319
54Y9309	1	Slim New F5 USB Greek/US459
54Y9310	1	Slim New F5 USB Hebrew 212
54Y9311	1	Slim New F5 USB Hungarian 208
54Y9312	1	Slim New F5 USB Iceland 197

54Y9313	1	Slim New F5 USB Italy 141
54Y9314	1	Slim New F5 USB Japanese194
54Y9315	1	Slim New F5 USB Korean413
54Y9316	1	Slim New F5 USB LA Spanish 171
54Y9317	1	Slim New F5 USB Norwegian 155
54Y9318	1	Slim New F5 USB Polish 214
54Y9319	1	Slim New F5 USB Portugese 163
54Y9320	1	Slim New F5 USB Romanian96
54Y9321	1	Slim New F5 USB Russian/Cy441
54Y9322	1	Slim New F5 USB Serbian/Cyrilic 118
54Y9323	1	Slim New F5 USB Slovak245
54Y9324	1	Slim New F5 USB Spanish 172
54Y9325	1	Slim New F5 USB Swedish/Finn 153
54Y9326	1	Slim New F5 USB Swiss, F/G 150
54Y9327	1	Slim New F5 USB Thailand 191
54Y9328	1	Slim New F5 USB Turkish (TF)440
54Y9329	1	Slim New F5 USB Turkish (TQ)179
54Y9330	1	Slim New F5 USB UK English 166
54Y9331	1	Slim New F5 USB US Euro103P
54Y9332	1	Slim New F5 USB Slovenian234
54Y9333	1	Slim New F5 USB Arabic(New)470
54Y9334	1	Slim New F5 USB Lithuanian494
54Y9335	1	Slim New F5 USB ESTONIAN454
54Y9336	1	Slim New F5 USB Nordic
54Y9400	1	NetVista Keyboard (USB)
54Y9401	1	NetVista Keyboard (USB)
54Y9402	1	NetVista Keyboard (USB)
54Y9403	1	NetVista Keyboard (USB)
54Y9404	1	NetVista Keyboard (USB)
54Y9405	1	NetVista Keyboard (USB)
54Y9406	1	NetVista Keyboard (USB)
54Y9407	1	NetVista Keyboard (USB)
54Y9408	1	NetVista Keyboard (USB)
54Y9409	1	NetVista Keyboard (USB)
54Y9410	1	NetVista Keyboard (USB)
54Y9411	1	NetVista Keyboard (USB)
54Y9412	1	NetVista Keyboard (USB)
54Y9413	1	NetVista Keyboard (USB)
54Y9414	1	NetVista Keyboard (USB)
54Y9415	1	NetVista Keyboard (USB)
54Y9416	1	NetVista Keyboard (USB)
54Y9417	1	NetVista Keyboard (USB)
54Y9418	1	NetVista Keyboard (USB)
54Y9419	1	NetVista Keyboard (USB)
54Y9420	1	NetVista Keyboard (USB)
54Y9422	1	NetVista Keyboard (USB)
54Y9423	1	NetVista Keyboard (USB)
54Y9424	1	NetVista Keyboard (USB)
54Y9425	1	NetVista Keyboard (USB)
54Y9426	1	NetVista Keyboard (USB)
54Y9427	1	NetVista Keyboard (USB)
54Y9428	1	NetVista Keyboard (USB)

54Y9429	1	NetVista Keyboard (USB)
54Y9430	1	NetVista Keyboard (USB)
54Y9431	1	NetVista Keyboard (USB)
54Y9432	1	NetVista Keyboard (USB)
54Y9433	1	NetVista Keyboard (USB)
54Y9434	1	NetVista Keyboard (USB)
54Y9435	1	NetVista Keyboard (USB)
54Y9436	1	NetVista Keyboard (USB)
54Y9437	1	NetVista Keyboard (USB)
54Y9438	1	NetVista Keyboard (USB)
54Y9439	1	NetVista Keyboard (USB)
54Y9440	1	NetVista Keyboard (USB)
54Y9441	1	NetVista Keyboard (USB)
54Y9442	1	NetVista Keyboard (USB)
54Y9443	1	NetVista Keyboard (USB)
54Y9444	1	NetVista Keyboard (USB)
54Y9445	1	NetVista Keyboard (USB)
54Y9446	1	NetVista Keyboard (USB)
54Y9447	1	NetVista Keyboard (PS2)
54Y9448	1	NetVista Keyboard (PS2)
54Y9449	1	NetVista Keyboard (PS2)
54Y9450	1	NetVista Keyboard (PS2)
54Y9451	1	NetVista Keyboard (PS2)
54Y9452	1	NetVista Keyboard (PS2)
54Y9453	1	NetVista Keyboard (PS2)
54Y9454	1	NetVista Keyboard (PS2)
54Y9455	1	NetVista Keyboard (PS2)
54Y9456	1	NetVista Keyboard (PS2)
54Y9457	1	NetVista Keyboard (PS2)
54Y9458	1	NetVista Keyboard (PS2)
54Y9459	1	NetVista Keyboard (PS2)
54Y9460	1	NetVista Keyboard (PS2)
54Y9461	1	NetVista Keyboard (PS2)
54Y9462	1	NetVista Keyboard (PS2)
54Y9463	1	NetVista Keyboard (PS2)
54Y9464	1	NetVista Keyboard (PS2)
54Y9465	1	NetVista Keyboard (PS2)
54Y9466	1	NetVista Keyboard (PS2)
54Y9467	1	NetVista Keyboard (PS2)
54Y9469	1	NetVista Keyboard (PS2)
54Y9470	1	NetVista Keyboard (PS2)
54Y9471	1	NetVista Keyboard (PS2)
54Y9472	1	NetVista Keyboard (PS2)
54Y9473	1	NetVista Keyboard (PS2)
54Y9474	1	NetVista Keyboard (PS2)
54Y9475	1	NetVista Keyboard (PS2)
54Y9476	1	NetVista Keyboard (PS2)
54Y9477	1	NetVista Keyboard (PS2)
54Y9478	1	NetVista Keyboard (PS2)
54Y9479	1	NetVista Keyboard (PS2)
54Y9480	1	NetVista Keyboard (PS2)
54Y9481	1	NetVista Keyboard (PS2)

54Y9482	1	NetVista Keyboard (PS2)
54Y9483	1	NetVista Keyboard (PS2)
54Y9484	1	NetVista Keyboard (PS2)
54Y9485	1	NetVista Keyboard (PS2)
54Y9486	1	NetVista Keyboard (PS2)
54Y9487	1	NetVista Keyboard (PS2)
54Y9488	1	NetVista Keyboard (PS2)
54Y9489	1	Edge KB New F5 USB
54Y9490	1	Edge KB New F5 USB
54Y9491	1	Edge KB New F5 USB
54Y9492	1	Edge KB New F5 USB
54Y9493	1	Edge KB New F5 USB
54Y9494	1	Edge KB New F5 USB
54Y9495	1	Edge KB New F5 USB
54Y9496	1	Edge KB New F5 USB
54Y9497	1	Edge KB New F5 USB
54Y9498	1	Edge KB New F5 USB
54Y9499	1	Edge KB New F5 USB
54Y9500	1	Edge KB New F5 USB
54Y9501	1	Edge KB New F5 USB
54Y9502	1	Edge KB New F5 USB
54Y9503	1	Edge KB New F5 USB
54Y9504	1	Edge KB New F5 USB
54Y9505	1	Edge KB New F5 USB
54Y9506	1	Edge KB New F5 USB
54Y9507	1	Edge KB New F5 USB
54Y9508	1	Edge KB New F5 USB
54Y9509	1	Edge KB New F5 USB
54Y9511	1	Edge KB New F5 USB
54Y9512	1	Edge KB New F5 USB
54Y9513	1	Edge KB New F5 USB
54Y9514	1	Edge KB New F5 USB
54Y9515	1	Edge KB New F5 USB
54Y9516	1	Edge KB New F5 USB
54Y9517	1	Edge KB New F5 USB
54Y9518	1	Edge KB New F5 USB
54Y9519	1	Edge KB New F5 USB
54Y9520	1	Edge KB New F5 USB
54Y9521	1	Edge KB New F5 USB
54Y9522	1	Edge KB New F5 USB
54Y9523	1	Edge KB New F5 USB
54Y9524	1	Edge KB New F5 USB
54Y9525	1	Edge KB New F5 USB
54Y9526	1	Edge KB New F5 USB
54Y9527	1	Edge KB New F5 USB
54Y9528	1	Edge KB New F5 USB
54Y9529	1	Edge KB New F5 USB
54Y9530	1	Edge KB New F5 USB
54Y9531	1	Edge KB New F5 USB
54Y9532	1	Edge KB New F5 USB
54Y9534	1	Edge KB New F5 USB
54Y9535	1	Edge KB New F5 USB

54Y9536	1	Fingerprint(EPEAT GOLD) KB
54Y9537	1	Fingerprint(EPEAT GOLD) KB
54Y9538	1	Fingerprint(EPEAT GOLD) KB
54Y9539	1	Fingerprint(EPEAT GOLD) KB
54Y9540	1	Fingerprint(EPEAT GOLD) KB
54Y9541	1	Fingerprint(EPEAT GOLD) KB
54Y9542	1	Fingerprint(EPEAT GOLD) KB
54Y9543	1	Fingerprint(EPEAT GOLD) KB
54Y9544	1	Fingerprint(EPEAT GOLD) KB
54Y9545	1	Fingerprint(EPEAT GOLD) KB
54Y9546	1	Fingerprint(EPEAT GOLD) KB
54Y9547	1	Fingerprint(EPEAT GOLD) KB
54Y9548	1	Fingerprint(EPEAT GOLD) KB
54Y9549	1	Fingerprint(EPEAT GOLD) KB
54Y9550	1	Fingerprint(EPEAT GOLD) KB
54Y9551	1	Fingerprint(EPEAT GOLD) KB
54Y9552	1	Fingerprint(EPEAT GOLD) KB
54Y9553	1	Fingerprint(EPEAT GOLD) KB
54Y9554	1	Fingerprint(EPEAT GOLD) KB
54Y9555	1	Fingerprint(EPEAT GOLD) KB
54Y9556	1	Fingerprint(EPEAT GOLD) KB
54Y9558	1	Fingerprint(EPEAT GOLD) KB
54Y9559	1	Fingerprint(EPEAT GOLD) KB
54Y9560	1	Fingerprint(EPEAT GOLD) KB
54Y9561	1	Fingerprint(EPEAT GOLD) KB
54Y9562	1	Fingerprint(EPEAT GOLD) KB
54Y9563	1	Fingerprint(EPEAT GOLD) KB
54Y9564	1	Fingerprint(EPEAT GOLD) KB
54Y9565	1	Fingerprint(EPEAT GOLD) KB
54Y9566	1	Fingerprint(EPEAT GOLD) KB
54Y9567	1	Fingerprint(EPEAT GOLD) KB
54Y9568	1	Fingerprint(EPEAT GOLD) KB
54Y9569	1	Fingerprint(EPEAT GOLD) KB
54Y9570	1	Fingerprint(EPEAT GOLD) KB
54Y9571	1	Fingerprint(EPEAT GOLD) KB
54Y9572	1	Fingerprint(EPEAT GOLD) KB
54Y9573	1	Fingerprint(EPEAT GOLD) KB
54Y9574	1	Fingerprint(EPEAT GOLD) KB
54Y9575	1	Fingerprint(EPEAT GOLD) KB
54Y9576	1	Fingerprint(EPEAT GOLD) KB
MOUSE		
45J4889	1	Optical Wheel Mouse USB
03X6004	1	USB Laser Mouse
LINECORDS		
24R2632	1	3/2 Con. Plug
24R2633	1	Japan Cord Grp
41R3175	1	Fig.68--1.8m
41R3176	1	1.8mIRAM Cable
41R3184	1	1.8m Powercord
41R3196	1	1.8m Powercord
41R3208	1	1.8m Powercord
41R3212	1	1.8m Powercord

41R3220	1	1.8m Powercord
41R3224	1	1.8m Powercord
41R3228	1	1.8m Powercord
41R3232	1	1.8m Powercord
41R3236	1	1.8m Powercord
41R3252	1	1.8m Powercord
41R3256	1	1.8m Powercord
41R3260	1	1.8m Powercord
41R3278	1	1.8m Powercord
43N9029	1	TIS 250V C13
43N9057	1	Cable Group
45J9595	1	1.8m linecord
RECOVERY MEDIA		
03T2887	1	Adobe PremiereElements 10
03T6427	1	Adobe Acrobat X Standard
03W3594	1	Windows 7 HBx32 AR/EN
03W3595	1	Windows 7 HBx32 BR
03W3596	1	Windows 7 HBx32 FR
03W3597	1	Windows 7 HBx32 RU
03W3598	1	Windows 7 HBx32 SP
03W3599	1	Windows 7 HBx32 PO/EN
03W3600	1	Windows 7 HBx32 SR/EN
04X7702	1	Windows 7 HBx32 TR/EN
04X7704	1	Windows 7 HBx64 AR/EN
04X7705	1	Windows 7 HBx64 BR
04X7706	1	Windows 7 HBx64 FR
04X7707	1	Windows 7 HBx64 PO/EN
04X7708	1	Windows 7 HBx64 RU
04X7709	1	Windows 7 HBx64 SP
04X7710	1	Windows 7 HBx64 SR/EN
04X7711	1	Windows 7 HBx64 TR/EN
04X7713	1	Windows 7 HPx32 FR
04X7714	1	Windows 7 HPx32 GR
04X7716	1	Windows 7 HPx32 KR/EN
04X7717	1	Windows 7 HPx32 SP
04X7719	1	Windows 7 HPx64 FR
04X7720	1	Windows 7 HPx64 GR
04X7722	1	Windows 7 HPx64 KR/EN
04X7723	1	Windows 7 HPx64 SP
04X7726	1	Windows 7 PROx32 FR
04X7727	1	Windows 7 PROx32 GR
04X7729	1	Windows 7 PROx32 SP
04X7731	1	Windows 7 PROx64 AR/EN
04X7732	1	Windows 7 PROx64 BR
04X7734	1	Windows 7 PROx64 CT/EN
04X7735	1	Windows 7 PROx64 CZ/EN
04X7736	1	Windows 7 PROx64 FR
04X7737	1	Windows 7 PROx64 GK/EN
04X7738	1	Windows 7 PROx64 GR
04X7739	1	Windows 7 PROx64 HB/EN
04X7740	1	Windows 7 PROx64 HK/EN
04X7741	1	Windows 7 PROx64 HU/EN

04X7743	1	Windows 7 PROx64 KR/EN
04X7744	1	Windows 7 PROx64 PL
04X7745	1	Windows 7 PROx64 PO/EN
04X7746	1	Windows 7 PROx64 RO/EN
04X7747	1	Windows 7 PROx64 RU
04X7748	1	Windows 7 PROx64 SK/EN
04X7749	1	Windows 7 PROx64 SP
04X7750	1	Windows 7 PROx64 SR/EN
04X7751	1	Windows 7 PROx64 TR/EN
04X7753	1	Windows 7 PROx64 C&L EMEA
04X7754	1	Windows 7 PROx64 C&L Nordics
04X7755	1	Windows 7 PROx64 C&L SL/CR/EN
04X7759	1	Windows 8 SLx64 AR/EN
04X7760	1	Windows 8 SLx64 BR
04X7761	1	Windows 8 SLx64 FR
04X7762	1	Windows 8 SLx64 PO/EN
04X7763	1	Windows 8 SLx64 RU
04X7764	1	Windows 8 SLx64 SP
04X7765	1	Windows 8 SLx64 SR/EN
04X7766	1	Windows 8 SLx64 TR/EN
04X7768	1	Windows 8 PROx64 AR/EN
04X7769	1	Windows 8 PROx64 BR
04X7771	1	Windows 8 PROx64 CT/EN
04X7772	1	Windows 8 PROx64 CZ/EN
04X7773	1	Windows 8 PROx64 FR
04X7774	1	Windows 8 PROx64 GK/EN
04X7775	1	Windows 8 PROx64 GR
04X7776	1	Windows 8 PROx64 HB/EN
04X7777	1	Windows 8 PROx64 HK/EN
04X7778	1	Windows 8 PROx64 HU/EN
04X7780	1	Windows 8 PROx64 KR/EN
04X7781	1	Windows 8 PROx64 PL
04X7782	1	Windows 8 PROx64 PO/EN
04X7783	1	Windows 8 PROx64 RO/EN
04X7784	1	Windows 8 PROx64 RU
04X7785	1	Windows 8 PROx64 SK/EN
04X7786	1	Windows 8 PROx64 SP
04X7787	1	Windows 8 PROx64 SR/EN
04X7788	1	Windows 8 PROx64 TR/EN
04X7790	1	Windows 8 PROx64 C&L EMEA
04X7791	1	Windows 8 PROx64 C&L Nordics
04X7792	1	Windows 8 PROx64 C&L SL/CR/EN
04X7794	1	Windows 8 x64 CT/EN
04X7795	1	Windows 8 x64 CZ/EN
04X7796	1	Windows 8 x64 FR
04X7797	1	Windows 8 x64 GK/EN
04X7798	1	Windows 8 x64 GR
04X7799	1	Windows 8 x64 HB/EN
04X7800	1	Windows 8 x64 HK/EN
04X7801	1	Windows 8 x64 HU/EN
04X7803	1	Windows 8 x64 KR/EN
04X7804	1	Windows 8 x64 PL

04X7805	1	Windows 8 x64 PO/EN
04X7806	1	Windows 8 x64 RO/EN
04X7807	1	Windows 8 x64 SK/EN
04X7808	1	Windows 8 x64 SP
04X7810	1	Windows 8 x64 C&L EMEA
04X7811	1	Windows 8 x64 C&L Nordics
04X7812	1	Windows 8 x64 C&L SL/CR/EN
04X7813	1	Windows 7 HBx32 SP1 US
04X7814	1	Windows 7 HBx64 SP1 US
04X7815	1	Windows 7 HPx32 SP1 JP/EN
04X7816	1	Windows 7 HPx32 SP1 US
04X7817	1	Windows 7 HPx64 SP1 JP/EN
04X7818	1	Windows 7 HPx64 SP1 US
04X7819	1	Windows 7 PROx32 SP1 CS
04X7820	1	Windows 7 PROx32 SP1 JP/EN
04X7821	1	Windows 7 PROx32 SP1 US
04X7822	1	Windows 7 PROx64 SP1 CS
04X7823	1	Windows 7 PROx64 SP1 JP/EN
04X7824	1	Windows 7 PROx64 SP1 US
04X7827	1	Windows 8 CNx64 CS
04X7828	1	Windows 8 SLx64 US
04X7829	1	Windows 8 PROx64 CS
04X7830	1	Windows 8 PROx64 JP/EN
04X7831	1	Windows 8 PROx64 US
04X7832	1	Windows 8 x64 CS
04X7833	1	Windows 8 x64 JP/EN
04X7834	1	Windows 8 x64 US