

ThinkPad Tablet 8; MT 20BN, 20BQ

PN	CRU ID	Description
AC ADAPTERS		
45N0516	1	PI 10W China type - Primary
45N0518	1	PI 10W Argentina type - Primary
45N0520	1	PI 10W US type - Primary
45N0522	1	PI 10W UK type - Primary
45N0524	1	PI 10W Korea type - Primary
45N0526	1	PI 10W Australia type - Primary
45N0528	1	PI 10W EU type - Primary
45N0530	1	Liteon 10W adapter China type - Secondary
45N0532	1	Liteon 10W adapter Argentina type - Secondary
45N0534	1	Liteon 10W adapter US type - Secondary
45N0536	1	Liteon 10W adapter UK type - Secondary
45N0538	1	Liteon 10W adapter Korea type - Secondary
45N0540	1	Liteon 10W adapter Australia type - Secondary
45N0542	1	Liteon 10W EU type adapter - Secondary
ANTENNA		
00HM117	N	WLAN antenna ASM
00HM118	N	WWAN antenna - US ASM
00HM119	N	WWAN antenna - ROW ASM
BATTERIES		
45N1715	N	Panasonic 2cell (1s2p) / 20.5Wh polymer battery - Primary
45N1717	N	Sony 2cell (1s2p) / 20.5Wh polymer battery - Secondary
45N1719	N	Simplo 2cell (1s2p) / 20.5Wh polymer battery - Secondary
PLANARS		
00HM055	N	Planar - 64GB 2GB W8.1-PRO w/o WWAN slot
00HM056	N	Planar - 128GB 2GB W8.1-PRO w/o WWAN slot
00HM058	N	Planar - 64GB 2GB W8.1-PRO w WWAN slot
00HM059	N	Planar - 128GB 2GB W8.1-PRO w WWAN slot
00HM061	N	Planar - 64GB 2GB W8.1-STD w/o WWAN slot
00HM062	N	Planar - 128GB 2GB W8.1-STD w/o WWAN slot
00HM064	N	Planar - 64GB 2GB W8.1-STD w WWAN slot
00HM065	N	Planar - 128GB 2GB W8.1-STD w WWAN slot
BRACKETS		
00HM120	N	LCD Support Bracket
00HM126	N	T-com Bracket
00HM175	N	Micro USB Bracket
CABLES		
00HM037	N	USB 3.0 DC Cable
00HM122	N	Audio Flat Cable
00HM123	N	eDP Flat Cable
00HM124	N	T/S Flat Cable
CAMERAS		
04X0296	N	Abico 8M Camera - Secondary
04X1390	N	Liteon 2M Camera

04X1391	N	Liteon 8M Camera - Primary
COVERS		
00HM115	N	Back Cover (Black) w/o antenna window
00HM116	N	Back Cover (Black) w/ antenna window
00HM252	N	Back Cover (Black) w/o antenna window China wifi
LCD'S		
00HM112	N	Touch LCD ASM LGD 8.3 IPS WUXGA
RECOVERY MEDIA		
00EW727	1	DVD Win8.1 Pro32 REC USB Key AR/EN
00EW728	1	DVD Win8.1 Pro32 REC USB Key BR
00EW729	1	DVD Win8.1 Pro32 REC USB Key CS
00EW730	1	DVD Win8.1 Pro32 REC USB Key HK/EN
00EW731	1	DVD Win8.1 Pro32 REC USB Key CT/EN
00EW732	1	DVD Win8.1 Pro32 REC USB Key CZ/EN
00EW733	1	DVD Win8.1 Pro32 REC USB Key FR
00EW734	1	DVD Win8.1 Pro32 REC USB Key GR
00EW735	1	DVD Win8.1 Pro32 REC USB Key GK/EN
00EW736	1	DVD Win8.1 Pro32 REC USB Key HB/EN
00EW737	1	DVD Win8.1 Pro32 REC USB Key HU/EN
00EW738	1	DVD Win8.1 Pro32 REC USB Key JP
00EW739	1	DVD Win8.1 Pro32 REC USB Key KR/EN
00EW740	1	DVD Win8.1 Pro32 REC USB Key PL
00EW741	1	DVD Win8.1 Pro32 REC USB Key PO/EN
00EW742	1	DVD Win8.1 Pro32 REC USB Key RO/EN
00EW743	1	DVD Win8.1 Pro32 REC USB Key RU
00EW744	1	DVD Win8.1 Pro32 REC USB Key SR/EN
00EW745	1	DVD Win8.1 Pro32 REC USB Key SK/EN
00EW746	1	DVD Win8.1 Pro32 REC USB Key SP
00EW747	1	DVD Win8.1 Pro32 REC USB Key TR/EN
00EW748	1	DVD Win8.1 Pro32 REC USB Key US
00EW749	1	DVD Win8.1 Pro32 REC USB Key C&L Nordics (EN DK FI NO SV)
00EW750	1	DVD Win8.1 Pro32 REC USB Key C&L EMEA(EN FR GR IT)
00EW751	1	DVD Win8.1 Pro32 REC USB Key C&L Croatian (EN/SL/CR)
00EW752	1	DVD Win8.1 Pro32 REC USB Key AR/EN
00EW753	1	DVD Win8.1 Pro32 REC USB Key BR
00EW754	1	DVD Win8.1 Pro32 REC USB Key HK/EN
00EW755	1	DVD Win8.1 Pro32 REC USB Key CT/EN
00EW756	1	DVD Win8.1 Pro32 REC USB Key CZ/EN
00EW757	1	DVD Win8.1 Pro32 REC USB Key FR
00EW758	1	DVD Win8.1 Pro32 REC USB Key GR
00EW759	1	DVD Win8.1 Pro32 REC USB Key GK/EN
00EW760	1	DVD Win8.1 Pro32 REC USB Key HB/EN
00EW761	1	DVD Win8.1 Pro32 REC USB Key HU/EN
00EW762	1	DVD Win8.1 Pro32 REC USB Key KR/EN
00EW763	1	DVD Win8.1 Pro32 REC USB Key PL
00EW764	1	DVD Win8.1 Pro32 REC USB Key PO/EN
00EW765	1	DVD Win8.1 Pro32 REC USB Key RO/EN

00EW766	1	DVD Win8.1 Pro32 REC USB Key RU
00EW767	1	DVD Win8.1 Pro32 REC USB Key SR/EN
00EW768	1	DVD Win8.1 Pro32 REC USB Key SK/EN
00EW769	1	DVD Win8.1 Pro32 REC USB Key SP
00EW770	1	DVD Win8.1 Pro32 REC USB Key TR/EN
00EW771	1	DVD Win8.1 Pro32 REC USB Key US
00EW772	1	DVD Win8.1 Pro32 REC USB Key C&L Nordics (EN DK FI NO SV)
00EW773	1	DVD Win8.1 Pro32 REC USB Key C&L EMEA(EN FR GR IT)
00EW774	1	DVD Win8.1 Pro32 REC USB Key C&L Croatian (EN/SL/CR)
00EW775	1	DVD Win8.1 Pro32 REC USB Key JP
00EW776	1	DVD Win8.1 Pro32 REC USB Key CS
00LC271	1	DVD Win8.1 Pro64 REC USB Key JP
00LC304	1	DVD Win8.1 Pro64 Bing REC USB Key US
00LC308	1	DVD Win8.1 64 Bing REC USB Key JP
00LC331	1	DVD Win8.1 Pro32 Bing REC USB Key US
00LC358	1	DVD Win8.1 32 Bing REC USB Key JP
MISC		
00HM129	N	Screw kit
00HM121	N	Speaker
00HM128	N	Sponge for Front cam
SUBCARDS AND WIRELESS CARDS		
04W3842	N	Ericsson N5321 HSPA+ 21Mbps M.2 WWAN Support Win8.1
04X6015	N	Sierra EM7345 LTE/HSPA+ 42Mbps M.2 Card
00HM127	N	Audio Board