

## Think Tablet FRU BOM; MT: 3679, 3682

Fru P/N	Cru Id	Description
<b>AC ADAPTERS</b>		
45N0442	1	PI 10W CHINA
45N0444	1	PI 10W US
45N0446	1	PI 10W EU
45N0448	1	PI 10W UK
45N0450	1	PI 10W Aus
45N0452	1	PI 10W KOREA
45N0454	1	PI 10W SA
45N0456	1	PI 10W ARG
45N0546	1	NEC PI 10W AC Adapter
<b>WIRELESS AND SUB-CARDS</b>		
04W3784	N	EM770
04W3793	N	NFC
04X4700	N	I/O board
04X0350	N	I/O board FPC
04X3995	N	Sierra EM7700 Docomo
04W3831	N	Sierra EM7700 Docomo
04X0383	N	Sierra EM7700 for CT
04X0384	N	Ericsson C5621 for CT
<b>ANTENNAS</b>		
04X0408	N	3G main antenna
04X0409	N	3G Aux antenna
04X0410	N	TunableWWANmain antennaA
04X0411	N	TunableWWANmain antennaF
04X0412	N	TunableWWAN Aux antennaA
04X0413	N	Tunabl WWAN Aux antennaF
04X0414	N	GPS antenna
04X0415	N	WLAN MAIN antenna
04X0416	N	WLAN AUX antenna
<b>BATTERIES</b>		
45N1097	N	P-SANYO 4cell 30Wh
45N1099	N	LGC 6cell 30Wh
45N1721	N	FRU Panasonic 4cell (1s4p ) / 30Wh battery for NEC logo product
<b>PLANARS</b>		
00HN786	N	Planar - 64GB, 2GB, W8P, Y-TPM, BIOS=W81
00HN787	N	Planar - 64GB, 2GB, W8P, WO-TPM, BIOS=W81
00HN788	N	Planar - 64GB, 2GB, W8P, Y-TPM, NFC, BIOS=W81
00HN789	N	Planar - 64GB, 2GB, W8P, WO-TPM, NFC, BIOS=W81
00HN790	N	Planar - 64GB, 2GB, W8P, Y-TPM, New SIM, BIOS=W81
00HN791	N	Planar - 64GB, 2GB, W8P, WO-TPM, New SIM, BIOS=W81
00HN792	N	Planar - 64GB, 2GB, W8P, Y-TPM, NFC, New SIM, BIOS=W81
00HN793	N	Planar - 64GB, 2GB, W8P, WO-TPM, NFC, New SIM, BIOS=W81
00HN794	N	Planar - 64GB, 2GB, W8S, Y-TPM, BIOS=W81
00HN795	N	Planar - 64GB, 2GB, W8S, WO-TPM, BIOS=W81
00HN796	N	Planar - 64GB, 2GB, W8S, Y-TPM, NFC, BIOS=W81
00HN797	N	Planar - 64GB, 2GB, W8S, WO-TPM, NFC, BIOS=W81
00HN798	N	Planar - 64GB, 2GB, W8S, Y-TPM, New SIM, BIOS=W81

00HN799	N	Planar - 64GB, 2GB, W8S, WO-TPM, New SIM, BIOS=W81
00HN800	N	Planar - 64GB, 2GB, W8S, Y-TPM, NFC, New SIM, BIOS=W81
00HN801	N	Planar - 64GB, 2GB, W8S, WO-TPM, NFC, New SIM, BIOS=W81
00HN802	N	Planar - 32GB, 2GB, W8P, WO-TPM, BIOS=W81
00HN803	N	Planar - 32GB, 2GB, W8S, WO-TPM, BIOS=W81
00HW050	N	Planar - 64GB, 2GB, NOK, WO-TPM, BIOS=W81
04X4643	N	Planar - 32GB 2GB W8-PRO WO-TPM
04X4644	N	Planar - 32GB 2GB W8-STD WO-TPM ATML1386E
04X4645	N	Planar - 64GB 2GB W8-PRO Y-TPM ATML1386E New SIM
04X4646	N	Planar - 64GB 2GB W8-PRO Y-TPM NFC ATML1386E New SIM
04X4647	N	Planar - 64GB 2GB W8-STD Y-TPM ATML1386E New SIM
04X4648	N	Planar - 64GB 2GB W8-STD Y-TPM NFC ATML1386E New SIM
04X4649	N	Planar - 64GB 2GB W8-PRO WO-TPM ATML1386E New SIM
04X4650	N	Planar - 64GB 2GB W8-PRO WO-TPM NFC ATML1386E New SIM
04X4651	N	Planar - 64GB 2GB W8-STD WO-TPM ATML1386E New SIM
04X4652	N	Planar - 64GB 2GB W8-STD WO-TPM NFC ATML1386E New SIM
04X4653	N	Planar - 64GB 2GB W8-PRO Y-TPM New SIM for Wifi
04X4654	N	Planar - 64GB 2GB W8-PRO Y-TPM NFC New SIM for Wifi
04X4655	N	Planar - 64GB 2GB W8-STD Y-TPM New SIM for Wifi
04X4656	N	Planar - 64GB 2GB W8-STD Y-TPM NFC New SIM for Wifi
04X4657	N	Planar - 64GB 2GB W8-PRO WO-TPM New SIM for Wifi
04X4658	N	Planar - 64GB 2GB W8-PRO WO-TPM NFC New SIM for Wifi
04X4659	N	Planar - 64GB 2GB W8-STD WO-TPM New SIM for Wifi
04X4660	N	Planar - 64GB 2GB W8-STD WO-TPM NFC New SIM for Wifi
04X5229	N	Planar - NEC 64GB 2GB W7 N-OS WO-TPM
04X5230	N	Planar - NEC 64GB 2GB W7 N-OS WO-TPM New SIM
<b>BUTTONS</b>		
04X0389	N	Home Botton
04X0417	N	Power botton
04X0421	N	Volume Button
04X0422	N	Rotation Lock Button
<b>BRACKETS</b>		
04X0351	N	LVDS FPC
<b>CABLES</b>		
04W2153	N	Micro USB cable
04X0347	N	Digitizer FFC Cable
04X0348	N	Touchsensor FCC cable
04X0349	N	TFF FPC cable
04X0386	N	USB with FPC cable
04X0428	N	Switch FPC cable
04X0833	N	Micro USB cable
<b>CAMERAS</b>		
04W3022	N	OUT CAMERA LTN
04W3024	N	IN CAMERA LTN
<b>CAMERA LENSES</b>		
04X0419	N	Lens for rear Camera
04X0420	N	Lens for rear side LED
<b>MECHANICAL ASSEMBLIES</b>		
04X0385	N	BackCoverASM nFPRnNFC
04X0387	N	BZL asm

04X0423	N	SD Door
04X0424	N	USB Door
04X0517	N	Back Cover ASM for No NFC, new SIM w/ 2 doors and Cu sheet
04X0518	N	BackCover ASM NFC newSIM
04X0836	2	Shieldingsheet with Mylar
04X1757	N	Touchsensor board FW 1.3
04X3996	N	Thermalpad with adhesive
04X5139	N	Back Cover ASM (NEC) No NFC, new SIM w/ 2 doors and Cu sheet
04X5140	N	Stylus pen (NEC)
04X5142	N	Home button (NEC)
04X5143	N	Power button (NEC)
04X5484	N	Volume Button (NEC)
04X5485	N	Rotation Lock Button (NEC)
04X5486	N	SD Door (NEC)
04X5487	N	USB Door (NEC)
04Y1469	N	Pen cap
04Y1470	1	Stylus pen
04Y1471	N	Back Cover ASM for No-FPR, No-NFC w/ 2 doors and Cu sheet
04Y1473	N	NFC tag
04Y1485	N	Digitizer sheet
04Y1486	N	Touchsensor board
<b>LCD ASSEMBLIES</b>		
04X3810	N	10.1 IPS HD - LGD
04X3811	N	10.1 IPS HD with Dgt-LGD
04X5138	N	10.1" IPS HD with Digitizer - LGD (NEC)
<b>KEYBOARDS</b>		
04X5483	N	Booklet - NEC Japanese
04Y1488	N	Booklet KBD - USE
04Y1489	N	Booklet KBD - CFR
04Y1490	N	Booklet KBD - ARA
04Y1491	N	Booklet KBD - BLG
04Y1492	N	Booklet KBD- CZH
04Y1493	N	Booklet KBD- DEN
04Y1494	N	Booklet KBD- SPA
04Y1495	N	Booklet KBD- FRA
04Y1496	N	Booklet KBD- GER
04Y1497	N	Booklet KBD- GR US
04Y1498	N	Booklet KBD- HUG
04Y1499	N	Booklet KBD- ISR(HBW)
04Y1500	N	Booklet KBD- ITA
04Y1501	N	Booklet KBD- NLD
04Y1502	N	Booklet KBD- NOR
04Y1503	N	Booklet KBD- POL
04Y1504	N	Booklet KBD- POR
04Y1505	N	Booklet KBD- RUS
04Y1506	N	Booklet KBD- SVK
04Y1507	N	Booklet KBD- SVN
04Y1508	N	Booklet KBD- SWE
04Y1509	N	Booklet KBD- SWS
04Y1510	N	Booklet KBD- TUR

04Y1511	N	Booklet KBD- UKE
04Y1512	N	Booklet KBD- USI
04Y1513	N	Booklet KBD- ISL
04Y1514	N	Booklet KBD- BGR
04Y1515	N	Booklet KBD- JPN
04Y1516	N	Booklet KBD- TWN
04Y1517	N	Booklet KBD- THA
04Y1518	N	Booklet KBD- KOR
04Y1519	N	Booklet KBD- IND
04Y1520	N	Booklet KBD- LAS
04Y1522	N	Booklet - ACF
04Y1523	N	Booklet - EST
<b>RECOVERY MEDIA (DVD's and USB Keys)</b>		
00EW501	1	DVD WIN8-Pro32 US
00EW502	1	DVD WIN8-Pro32 EI
00EW503	1	DVD WIN8-32 US
00EW504	1	DVD WIN8-32 EI
00EW505	1	DVD WIN8-SL32 US
00EW506	1	DVD WIN8-SL32 EI
00EW511	1	DVDWin8 REC USBKey AR/EN
00EW512	1	DVDWin8 REC USBKey RU
00EW513	1	DVDWin8 REC USBKey SR/EN
00EW514	1	DVDWin8 REC USBKey TR/EN
00EW515	1	DVDWin8 REC USBKey AR/EN
00EW516	1	DVDWin8 REC USBKey HK/EN
00EW517	1	DVDWin8 REC USBKey CT/EN
00EW518	1	DVDWin8 REC USBKeyCZ/EN
00EW519	1	DVDWin8 REC USBKeyFR
00EW520	1	DVDWin8 REC USBKeyGR
00EW521	1	DVDWin8 REC USBKeyGK/EN
00EW522	1	DVDWin8 REC USBKeyHB/EN
00EW523	1	DVDWin8 REC USBKeyHU/EN
00EW524	1	DVDWin8 REC USBKeyJP
00EW525	1	DVDWin8 REC USBKeyKR/EN
00EW526	1	DVDWin8 REC USBKeyPL
00EW527	1	DVDWin8 REC USBKeyPO/EN
00EW528	1	DVDWin8 REC USBKeyRO/EN
00EW529	1	DVDWin8 REC USBKeyRU
00EW530	1	DVDWin8 REC USBKeySR/EN
00EW531	1	DVDWin8 REC USBKeySK/EN
00EW532	1	DVDWin8 REC USBKeySP
00EW533	1	DVDWin8 REC USBKeyTR/EN
00EW534	1	DVDWin8 REC USBKeyUS
00EW536	1	DVD Win8 REC USBKeyC&L Nordics (EN DK FI NO SV)
00EW537	1	DVD Win8 REC USBKeyC&L EMEA (EN FR GR IT)
00EW538	1	DVD Win8 REC USBKeyC&L Croatian (EN/SL/CR)
00EW539	1	DVDWin8 REC USBKeyEI
00EW541	1	DVDWin8 REC USBKeyHK/EN
00EW542	1	DVDWin8 REC USBKeyCT/EN
00EW543	1	DVDWin8 REC USBKeyCZ/EN

00EW544	1	DVDWin8 REC USBKeyFR
00EW545	1	DVDWin8 REC USBKeyGR
00EW546	1	DVDWin8 REC USBKeyGK/EN
00EW547	1	DVDWin8 REC USBKeyHB/EN
00EW548	1	DVDWin8 REC USBKeyHU/EN
00EW549	1	DVDWin8 REC USBKeyJP
00EW550	1	DVDWin8 REC USBKeyKR/EN
00EW551	1	DVDWin8 REC USBKeyPL
00EW552	1	DVDWin8 REC USBKeyPO/EN
00EW553	1	DVDWin8 REC USBKeyRO/EN
00EW556	1	DVDWin8 REC USBKeySK/EN
00EW557	1	DVDWin8 REC USBKeySP
00EW559	1	DVDWin8 REC USBKeyUS
00EW561	1	DVD Win8 REC USBKeyC&L Nordics (EN DK FI NO SV)
00EW562	1	DVD Win8 REC USBKeyC&L EMEA (EN FR GR IT)
00EW563	1	DVD Win8 REC USBKeyC&L Croatian (EN/SL/CR)
00EW564	1	DVDWin8 REC USBKeyEI
00EW565	1	DVDWin8 REC USBKeyUS
00EW566	1	DVDWin8 REC USBKeyAR/EN
00EW567	1	DVDWin8 REC USBKeyFR
00EW568	1	DVDWin8 REC USBKeyPO/EN
00EW569	1	DVDWin8 REC USBKeyRU
00EW570	1	DVDWin8 REC USBKeySP
00EW571	1	DVDWin8 REC USBKeyTR/EN
00EW572	1	DVDWin8 REC USBKeyEI
00EW573	1	DVDWin8 REC USBKeySR/EN
00EW577	1	DVDWin8 REC USBKeyUS
00EW578	1	DVDWin8 REC USBKeyUS
00EW952	1	DVD Win8.1 Pro32 REC USB Key Arabic/English MUI
00EW953	1	DVD Win8.1 Pro32 REC USB Key Chinese Simplified
00EW954	1	DVD Win8.1 Pro32 REC USB Key Chinese Traditional (Hong-Kong)/English MUI
00EW955	1	DVD Win8.1 Pro32 REC USB Key Chinese Traditional (Taiwan)/English MUI
00EW956	1	DVD Win8.1 Pro32 REC USB Key Czech/English MUI
00EW957	1	DVD Win8.1 Pro32 REC USB Key French
00EW958	1	DVD Win8.1 Pro32 REC USB Key German
00EW959	1	DVD Win8.1 Pro32 REC USB Key Greek/English MUI
00EW960	1	DVD Win8.1 Pro32 REC USB Key Hebrew/English MUI
00EW961	1	DVD Win8.1 Pro32 REC USB Key Hungarian/English MUI
00EW962	1	DVD Win8.1 Pro32 REC USB Key Japanese
00EW963	1	DVD Win8.1 Pro32 REC USB Key Korean/English MUI
00EW964	1	DVD Win8.1 Pro32 REC USB Key Polish
00EW965	1	DVD Win8.1 Pro32 REC USB Key Portuguese/English MUI
00EW966	1	DVD Win8.1 Pro32 REC USB Key Romanian/English MUI
00EW967	1	DVD Win8.1 Pro32 REC USB Key Russian
00EW968	1	DVD Win8.1 Pro32 REC USB Key Serbia-Latin/English MUI
00EW969	1	DVD Win8.1 Pro32 REC USB Key Slovak/English MUI
00EW970	1	DVD Win8.1 Pro32 REC USB Key Spanish
00EW971	1	DVD Win8.1 Pro32 REC USB Key Turkish/English MUI
00EW972	1	DVD Win8.1 Pro32 REC USB Key English
00EW973	1	DVD Win8.1 Pro32 REC USB Key MUI Nordics (EN FI SV DK NO)

00EW974	1	DVD Win8.1 Pro32 REC USB Key MUI EMEA WE (EN FR GR IT NL)
00EW975	1	DVD Win8.1 Pro32 REC USB Key MUI Croatia (EN CR SL)
00EW976	1	DVD Win8.1 Pro32 REC USB Key English for India
00EW977	1	DVD WIN8.1-32 REC USB Key Arabic/English MUI
00EW978	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Hong-Kong)/English MUI
00EW979	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Taiwan)/English MUI
00EW980	1	DVD WIN8.1-32 REC USB Key Czech/English MUI
00EW981	1	DVD WIN8.1-32 REC USB Key French
00EW982	1	DVD WIN8.1-32 REC USB Key German
00EW983	1	DVD WIN8.1-32 REC USB Key Greek/English MUI
00EW984	1	DVD WIN8.1-32 REC USB Key Hebrew/English MUI
00EW985	1	DVD WIN8.1-32 REC USB Key Hungarian/English MUI
00EW986	1	DVD WIN8.1-32 REC USB Key Korean/English MUI
00EW987	1	DVD WIN8.1-32 REC USB Key Polish
00EW988	1	DVD WIN8.1-32 REC USB Key Portuguese/English MUI
00EW989	1	DVD WIN8.1-32 REC USB Key Romanian/English MUI
00EW990	1	DVD WIN8.1-32 REC USB Key Russian
00EW991	1	DVD WIN8.1-32 REC USB Key Serbia-Latin/English MUI
00EW992	1	DVD WIN8.1-32 REC USB Key Slovak/English MUI
00EW993	1	DVD WIN8.1-32 REC USB Key Spanish
00EW994	1	DVD WIN8.1-32 REC USB Key Turkish/English MUI
00EW995	1	DVD WIN8.1-32 REC USB Key English
00EW996	1	DVD WIN8.1-32 REC USB Key MUI Nordics (EN FI SV DK NO)
00EW997	1	DVD WIN8.1-32 REC USB Key MUI EMEA WE (EN FR GR IT NL)
00EW998	1	DVD WIN8.1-32 REC USB Key MUI Croatia (EN CR SL)
00EW999	1	DVD WIN8.1-32 REC USB Key English for India
00HU000	1	DVD Windows 8.1 32 SST REC USB Key Japanese
00HU001	1	DVD Win8 Edition 32 SST w/Office REC USB Key Chinese Simplified
00HU002	1	DVD WIN8.1-32 REC USB Key Arabic/English MUI
00HU003	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Hong-Kong)/English MUI
00HU004	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Taiwan)/English MUI
00HU005	1	DVD WIN8.1-32 REC USB Key Czech/English MUI
00HU006	1	DVD WIN8.1-32 REC USB Key French
00HU007	1	DVD WIN8.1-32 REC USB Key German
00HU008	1	DVD WIN8.1-32 REC USB Key Greek/English MUI
00HU009	1	DVD WIN8.1-32 REC USB Key Hebrew/English MUI
00HU010	1	DVD WIN8.1-32 REC USB Key Hungarian/English MUI
00HU011	1	DVD Windows 8.1 32 SST REC USB Key Japanese
00HU012	1	DVD WIN8.1-32 REC USB Key Korean/English MUI
00HU013	1	DVD WIN8.1-32 REC USB Key Polish
00HU014	1	DVD WIN8.1-32 REC USB Key Portuguese/English MUI
00HU015	1	DVD WIN8.1-32 REC USB Key Romanian/English MUI
00HU016	1	DVD WIN8.1-32 REC USB Key Russian
00HU017	1	DVD WIN8.1-32 REC USB Key Serbia-Latin/English MUI
00HU018	1	DVD WIN8.1-32 REC USB Key Slovak/English MUI
00HU019	1	DVD WIN8.1-32 REC USB Key Spanish
00HU020	1	DVD WIN8.1-32 REC USB Key Turkish/English MUI
00HU021	1	DVD WIN8.1-32 REC USB Key English
00HU022	1	DVD WIN8.1-32 REC USB Key MUI Nordics (EN FI SV DK NO)
00HU023	1	DVD WIN8.1-32 REC USB Key MUI EMEA WE (EN FR GR IT NL)

00HU024	1	DVD WIN8.1-32 REC USB Key MUI Croatia (EN CR SL)
00HU025	1	DVD WIN8.1-32 REC USB Key English for India
00HU026	1	DVD WIN8.1-32 REC USB Key Arabic/English MUI
00HU027	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Hong-Kong)/English MUI
00HU028	1	DVD WIN8.1-32 REC USB Key Chinese Traditional (Taiwan)/English MUI
00HU029	1	DVD WIN8.1-32 REC USB Key Czech/English MUI
00HU030	1	DVD WIN8.1-32 REC USB Key French
00HU031	1	DVD WIN8.1-32 REC USB Key German
00HU032	1	DVD WIN8.1-32 REC USB Key Greek/English MUI
00HU033	1	DVD WIN8.1-32 REC USB Key Hebrew/English MUI
00HU034	1	DVD WIN8.1-32 REC USB Key Hungarian/English MUI
00HU035	1	DVD WIN8.1-32 REC USB Key Korean/English MUI
00HU036	1	DVD WIN8.1-32 REC USB Key Polish
00HU037	1	DVD WIN8.1-32 REC USB Key Portuguese/English MUI
00HU038	1	DVD WIN8.1-32 REC USB Key Romanian/English MUI
00HU039	1	DVD WIN8.1-32 REC USB Key Russian
00HU040	1	DVD WIN8.1-32 REC USB Key Serbia-Latin/English MUI
00HU041	1	DVD WIN8.1-32 REC USB Key Slovak/English MUI
00HU042	1	DVD WIN8.1-32 REC USB Key Spanish
00HU043	1	DVD WIN8.1-32 REC USB Key Turkish/English MUI
00HU044	1	DVD WIN8.1-32 REC USB Key English
00HU045	1	DVD WIN8.1-32 REC USB Key MUI Nordics (EN FI SV DK NO)
00HU046	1	DVD WIN8.1-32 REC USB Key MUI EMEA WE (EN FR GR IT NL)
00HU047	1	DVD WIN8.1-32 REC USB Key MUI Croatia (EN CR SL)
00HU048	1	DVD WIN8.1-32 REC USB Key English for India
00HU049	1	DVD Windows 8.1 32 SST REC USB Key Japanese
04T7640	1	WIN8-Pro32 AR/EN
04T7641	1	WIN8-Pro32 CS
04T7642	1	WIN8-Pro32 HK/EN
04T7643	1	WIN8-Pro32 CT/EN
04T7644	1	WIN8-Pro32 CZ/EN
04T7645	1	WIN8-Pro32 FR
04T7646	1	WIN8-Pro32 GR
04T7647	1	WIN8-Pro32 GK/EN
04T7648	1	WIN8-Pro32 HB/EN
04T7649	1	WIN8-Pro32 HU/EN
04T7650	1	WIN8-Pro32 JP
04T7651	1	WIN8-Pro32 KR/EN
04T7652	1	WIN8-Pro32 PL
04T7653	1	WIN8-Pro32 PO/EN
04T7654	1	WIN8-Pro32 RO/EN
04T7655	1	WIN8-Pro32 RU
04T7656	1	WIN8-Pro32 SR/EN
04T7657	1	WIN8-Pro32 SK/EN
04T7658	1	WIN8-Pro32 SP
04T7659	1	WIN8-Pro32 TR/EN
04T7662	1	WIN8-Pro32 C&L Nordics
04T7663	1	WIN8-Pro32 C&L EMEA
04T7664	1	WIN8-Pro32 C&L Croatian
04T7666	1	WIN8-32 HK/EN

04T7667	1	WIN8-32 CT/EN
04T7668	1	WIN8-32 CZ/EN
04T7669	1	WIN8-32 FR
04T7670	1	WIN8-32 GR
04T7671	1	WIN8-32 GK/EN
04T7672	1	WIN8-32 HB/EN
04T7673	1	WIN8-32 HU/EN
04T7674	1	WIN8-32 JP
04T7675	1	WIN8-32 KR/EN
04T7676	1	WIN8-32 PL
04T7677	1	WIN8-32 PO/EN
04T7678	1	WIN8-32 RO/EN
04T7679	1	WIN8-32 SK/EN
04T7680	1	WIN8-32 SP
04T7683	1	WIN8-32 C&L Nordics
04T7684	1	WIN8-32 C&L EMEA
04T7685	1	WIN8-32 C&L Croatian
04T7688	1	WIN8-SL32 AR/EN
04T7689	1	WIN8-SL32 FR
04T7690	1	WIN8-SL32 PO/EN
04T7691	1	WIN8-SL32 RU
04T7692	1	WIN8-SL32 SP
04T7693	1	WIN8-SL32 TR/EN
04T7695	1	WIN8-SL32 SR/EN
04T7697	1	Win8 REC USBKey HK/EN
04T7698	1	Win8 REC USBKey CT/EN
04T7699	1	Win8 REC USBKey CZ/EN
04T7700	1	Win8 REC USBKey FR
04T7701	1	Win8 REC USBKey GR
04T7702	1	Win8 REC USBKey GK/EN
04T7703	1	Win8 REC USBKey HB/EN
04T7704	1	Win8 REC USBKey HU/EN
04T7705	1	Win8 REC USBKey JP
04T7706	1	Win8 REC USBKey KR/EN
04T7707	1	Win8 REC USBKey PL
04T7708	1	Win8 REC USBKey PO/EN
04T7709	1	Win8 REC USBKey RO/EN
04T7710	1	Win8 REC USBKey SK/EN
04T7711	1	Win8 REC USBKey SP
04T7712	1	Win8 REC USBKey US
04T7714	1	Win8 REC USBKey C&L Nordics (EN DK FI NO SV)
04T7715	1	Win8 REC USBKey C&L EMEA(EN FR GR IT)
04T7716	1	Win8 REC USBKey C&L Croatian (EN/SL/CR)
04T7717	1	Win8 REC USBKey EI
04T7718	1	Win8 REC USBKey US
04T7719	1	Win8 REC USBKey AR/EN
04T7720	1	Win8 REC USBKey FR
04T7721	1	Win8 REC USBKey PO/EN
04T7722	1	Win8 REC USBKey RU
04T7723	1	Win8 REC USBKey SP

04T7724	1	Win8 REC USBKey TR/EN
04T7725	1	Win8 REC USBKey EI
04T7726	1	Win8 REC USBKey SR/EN
04T7728	1	Win8 REC USBKey HK/EN
04T7729	1	Win8 REC USBKey CT/EN
04T7730	1	Win8 REC USBKey CZ/EN
04T7731	1	Win8 REC USBKey FR
04T7732	1	Win8 REC USBKey GR
04T7733	1	Win8 REC USBKey GK/EN
04T7734	1	Win8 REC USBKey HB/EN
04T7735	1	Win8 REC USBKey HU/EN
04T7736	1	Win8 REC USBKey JP
04T7737	1	Win8 REC USBKey KR/EN
04T7738	1	Win8 REC USBKey PL
04T7739	1	Win8 REC USBKey PO/EN
04T7740	1	Win8 REC USBKey RO/EN
04T7741	1	Win8 REC USBKey SK/EN
04T7742	1	Win8 REC USBKey SP
04T7743	1	Win8 REC USBKey US
04T7744	1	Win8 REC USBKey UD
04T7745	1	Win8 REC USBKey C&L Nordics (EN DK FI NO SV
04T7746	1	Win8 REC USBKey C&L EMEA(EN FR GR IT)
04T7747	1	Win8 REC USBKey C&L Croatian (EN/SL/CR)
04T7748	1	Win8 REC USBKey EI
04T7749	1	Win8 REC USBKey US
04T7750	1	Win8 REC USBKey AR/EN
04T7751	1	Win8 REC USBKey FR
04T7752	1	Win8 REC USBKey PO/EN
04T7753	1	Win8 REC USBKey RU
04T7754	1	Win8 REC USBKey SP
04T7755	1	Win8 REC USBKey TR/EN
04T7756	1	Win8 REC USBKey EI
04T7757	1	Win8 REC USBKey SR/EN
04Y8192	1	DVDWin8 REC USBKeyAR/EN
04Y8193	1	DVDWin8 REC USBKeyHK/EN
04Y8194	1	DVDWin8 REC USBKeyCT/EN
04Y8195	1	DVDWin8 REC USBKeyCZ/EN
04Y8196	1	DVDWin8 REC USBKeyFR
04Y8197	1	DVDWin8 REC USBKeyGR
04Y8198	1	DVDWin8 REC USBKeyGK/EN
04Y8199	1	DVDWin8 REC USBKeyHB/EN
04Y8200	1	DVDWin8 REC USBKeyHU/EN
04Y8201	1	DVDWin8 REC USBKeyJP
04Y8202	1	DVDWin8 REC USBKeyKR/EN
04Y8203	1	DVDWin8 REC USBKeyPL
04Y8204	1	DVDWin8 REC USBKeyPO/EN
04Y8205	1	DVDWin8 REC USBKeyRO/EN
04Y8206	1	DVDWin8 REC USBKeyRU
04Y8207	1	DVDWin8 REC USBKeySR/EN
04Y8208	1	DVDWin8 REC USBKeySK/EN

04Y8209	1	DVDWin8 REC USBKeySP
04Y8210	1	DVDWin8 REC USBKeyTR/EN
04Y8212	1	DVDWin8 REC USBKeyUD
04Y8213	1	Win8 REC USBKeyC&L Nordics (EN DK FI NO SV)
04Y8214	1	DVD Win8 REC USBKeyC&L EMEA (EN FR GR IT)
04Y8215	1	DVD Win8 REC USBKeyC&L Croatian (EN/SL/CR)
04Y8216	1	DVDWin8 REC USBKeyEI
<b>MISC</b>		
03T6427	1	Adobe Acrobat X Standard
04X0344	N	Screw kit
04X0388	N	Fixing tape for cables
04X3828	N	Black tape 5x25
04Y2097	N	Speaker L
04Y2098	N	Speaker R