

ThinkCentre M32 Service Parts Listing

MT: 10BM, 10BV

FRU P/N	CRU ID	Description
PLANARS		
04X2282	N	FRU Planar Intel NM70
MEMORY		
03T7116	2	FRU 2GB 1600MHz DDR3 SODIMM
03T7117	2	FRU 4GB 1600MHz DDR3 SODIMM
HARD DISK DRIVES		
03T7233	2	FRU 8G DOM Card
04X2283	2	FRU 1G DOM Card
04X2284	2	FRU 16G DOM Card
ADAPTERS		
03X6262	N	FRU for Lenovo Slim Power Tip
03X6261	N	Slim Power Conversion Cable
03X6252	N	FRU CLA for adapter
CABLES		
03X6255	N	FRU CLA,input output Kits
03X6253	N	FRU 90W COMBO
03X6251	N	FRU CLA input cable
03X6259	N	FRU Indigo Car Charger
POWER SUPPLY		
43N9160	2	DP-DVI-D-S CBL
54Y8848	2	CRU,Tiny PC 65W adapter
MECHANICALS		
04X2261	N	Fru Top cover Assy of Clevel
04X2262	N	Fru Base cover Assy of Cleve
04X2263	N	Fru Vertical stand Cleveland
MOUSE		
51J0061	1	Fru Optical Wheel Mouse(PS2)
45J4889	1	FRU Optical Wheel Mouse USB
KEYBOARDS		
54Y9433	1	NetVista Keyboard (USB)
54Y9573	1	Fingerprint(EPEAT GOLD) KB
54Y9407	1	NetVista Keyboard (USB)
54Y9505	1	Edge KB New F5 USB
54Y9559	1	Fingerprint(EPEAT GOLD) KB
54Y9400	1	NetVista Keyboard (USB)
54Y9441	1	NetVista Keyboard (USB)
54Y9524	1	Edge KB New F5 USB
54Y9442	1	NetVista Keyboard (USB)
54Y9422	1	NetVista Keyboard (USB)
54Y9501	1	Edge KB New F5 USB
54Y9530	1	Edge KB New F5 USB
54Y9526	1	Edge KB New F5 USB
54Y9498	1	Edge KB New F5 USB
54Y9508	1	Edge KB New F5 USB

54Y9564	1	Fingerprint(EPEAT GOLD) KB
54Y9502	1	Edge KB New F5 USB
54Y9417	1	NetVista Keyboard (USB)
54Y9405	1	NetVista Keyboard (USB)
54Y9420	1	NetVista Keyboard (USB)
54Y9528	1	Edge KB New F5 USB
54Y9507	1	Edge KB New F5 USB
54Y9551	1	Fingerprint(EPEAT GOLD) KB
54Y9570	1	Fingerprint(EPEAT GOLD) KB
54Y9497	1	Edge KB New F5 USB
54Y9406	1	NetVista Keyboard (USB)
54Y9494	1	Edge KB New F5 USB
54Y9401	1	NetVista Keyboard (USB)
54Y9437	1	NetVista Keyboard (USB)
54Y9554	1	Fingerprint(EPEAT GOLD) KB
54Y9532	1	Edge KB New F5 USB
54Y9445	1	NetVista Keyboard (USB)
54Y9534	1	Edge KB New F5 USB
54Y9521	1	Edge KB New F5 USB
54Y9493	1	Edge KB New F5 USB
04X2610	1	Keyboard (USB) Arabic
54Y9496	1	Edge KB New F5 USB
04X2611	1	Keyboard (USB) Arabic/French
04X2612	1	Keyboard (USB) Belgium French
04X2614	1	Keyboard (USB) Bra/Por
04X2613	1	Keyboard (USB) Belgium English
04X2616	1	Keyboard (USB) Chinese/US
04X2615	1	Keyboard (USB) Bulgarian
04X2618	1	Keyboard (USB) Danish
04X2617	1	Keyboard (USB) Czech
04X2620	1	Keyboard (USB) French
04X2619	1	Keyboard (USB) Dutch
04X2622	1	Keyboard (USB) French Canadian
04X2621	1	Keyboard (USB) French Canadian
04X2625	1	Keyboard (USB) Greek/US
04X2623	1	Keyboard (USB) German
04X2627	1	Keyboard (USB) Hungarian
04X2626	1	Keyboard (USB) Hebrew
04X2629	1	Keyboard (USB) Italy
04X2628	1	Keyboard (USB) Iceland
04X2632	1	Keyboard (USB) Korean
04X2631	1	Keyboard (USB) Japanese
04X2634	1	Keyboard (USB) Norwegian
04X2633	1	Keyboard (USB) LA Spanish
04X2636	1	Keyboard (USB) Portugese
04X2635	1	Keyboard (USB) Polish
04X2638	1	Keyboard (USB) Russian/Cyrillic
04X2637	1	Keyboard (USB)Romanian

04X2640	1	Keyboard (USB) Slovak
04X2639	1	Keyboard (USB) Serbian/Cyrillic
04X2642	1	Keyboard (USB) Swedish/Finnish
04X2641	1	Keyboard (USB) Spanish
04X2649	1	Keyboard (USB) Slovenian
04X2643	1	Keyboard (USB) Swiss/French/Ger
04X2646	1	Keyboard (USB) Turkish
04X2648	1	Keyboard (USB) US Euro
04X2645	1	Keyboard (USB) Turkish
04X2647	1	Keyboard (USB) UK English
04X2644	1	Keyboard (USB) Thailand
04X2624	1	Keyboard (USB) Greek
04X2609	1	Keyboard (USB) US English
54Y9562	1	Fingerprint(EPEAT GOLD) KB
54Y9518	1	Edge KB New F5 USB
54Y9520	1	Edge KB New F5 USB
54Y9517	1	Edge KB New F5 USB
54Y9436	1	NetVista Keyboard (USB)
54Y9561	1	Fingerprint(EPEAT GOLD) KB
54Y9548	1	Fingerprint(EPEAT GOLD) KB
54Y9558	1	Fingerprint(EPEAT GOLD) KB
54Y9549	1	Fingerprint(EPEAT GOLD) KB
54Y9504	1	Edge KB New F5 USB
54Y9556	1	Fingerprint(EPEAT GOLD) KB
54Y9545	1	Fingerprint(EPEAT GOLD) KB
54Y9544	1	Fingerprint(EPEAT GOLD) KB
54Y9553	1	Fingerprint(EPEAT GOLD) KB
54Y9550	1	Fingerprint(EPEAT GOLD) KB
54Y9547	1	Fingerprint(EPEAT GOLD) KB
54Y9541	1	Fingerprint(EPEAT GOLD) KB
54Y9546	1	Fingerprint(EPEAT GOLD) KB
54Y9539	1	Fingerprint(EPEAT GOLD) KB
54Y9536	1	Fingerprint(EPEAT GOLD) KB
54Y9542	1	Fingerprint(EPEAT GOLD) KB
54Y9540	1	Fingerprint(EPEAT GOLD) KB
54Y9538	1	Fingerprint(EPEAT GOLD) KB
54Y9423	1	NetVista Keyboard (USB)
54Y9459	1	NetVista Keyboard (PS2)
54Y9488	1	NetVista Keyboard (PS2)
54Y9482	1	NetVista Keyboard (PS2)
54Y9443	1	NetVista Keyboard (USB)
54Y9535	1	Edge KB New F5 USB
54Y9529	1	Edge KB New F5 USB
54Y9531	1	Edge KB New F5 USB
54Y9427	1	NetVista Keyboard (USB)
54Y9414	1	NetVista Keyboard (USB)
54Y9575	1	Fingerprint(EPEAT GOLD) KB
54Y9413	1	NetVista Keyboard (USB)

54Y9512	1	Edge KB New F5 USB
54Y9424	1	NetVista Keyboard (USB)
54Y9515	1	Edge KB New F5 USB
54Y9523	1	Edge KB New F5 USB
54Y9428	1	NetVista Keyboard (USB)
54Y9572	1	Fingerprint(EPEAT GOLD) KB
54Y9418	1	NetVista Keyboard (USB)
54Y9426	1	NetVista Keyboard (USB)
54Y9506	1	Edge KB New F5 USB
54Y9415	1	NetVista Keyboard (USB)
54Y9522	1	Edge KB New F5 USB
54Y9537	1	Fingerprint(EPEAT GOLD) KB
54Y9471	1	NetVista Keyboard (PS2)
54Y9516	1	Edge KB New F5 USB
54Y9490	1	Edge KB New F5 USB
54Y9576	1	Fingerprint(EPEAT GOLD) KB
54Y9412	1	NetVista Keyboard (USB)
54Y9489	1	Edge KB New F5 USB
54Y9569	1	Fingerprint(EPEAT GOLD) KB
54Y9452	1	NetVista Keyboard (PS2)
54Y9503	1	Edge KB New F5 USB
54Y9568	1	Fingerprint(EPEAT GOLD) KB
54Y9495	1	Edge KB New F5 USB
54Y9454	1	NetVista Keyboard (PS2)
54Y9499	1	Edge KB New F5 USB
54Y9574	1	Fingerprint(EPEAT GOLD) KB
54Y9470	1	NetVista Keyboard (PS2)
54Y9514	1	Edge KB New F5 USB
54Y9410	1	NetVista Keyboard (USB)
54Y9560	1	Fingerprint(EPEAT GOLD) KB
54Y9511	1	Edge KB New F5 USB
54Y9447	1	NetVista Keyboard (PS2)
54Y9552	1	Fingerprint(EPEAT GOLD) KB
54Y9469	1	NetVista Keyboard (PS2)
54Y9430	1	NetVista Keyboard (USB)
54Y9543	1	Fingerprint(EPEAT GOLD) KB
54Y9491	1	Edge KB New F5 USB
54Y9509	1	Edge KB New F5 USB
54Y9411	1	NetVista Keyboard (USB)
54Y9571	1	Fingerprint(EPEAT GOLD) KB
54Y9409	1	NetVista Keyboard (USB)
54Y9416	1	NetVista Keyboard (USB)
54Y9513	1	Edge KB New F5 USB
54Y9408	1	NetVista Keyboard (USB)
54Y9566	1	Fingerprint(EPEAT GOLD) KB
54Y9567	1	Fingerprint(EPEAT GOLD) KB
54Y9525	1	Edge KB New F5 USB
54Y9563	1	Fingerprint(EPEAT GOLD) KB

54Y9402	1	NetVista Keyboard (USB)
54Y9492	1	Edge KB New F5 USB
54Y8410	1	FRU-Keyboard (USB)
54Y9439	1	NetVista Keyboard (USB)
54Y9429	1	NetVista Keyboard (USB)
54Y9440	1	NetVista Keyboard (USB)
54Y9432	1	NetVista Keyboard (USB)
54Y9527	1	Edge KB New F5 USB
54Y9435	1	NetVista Keyboard (USB)
54Y9500	1	Edge KB New F5 USB
54Y9565	1	Fingerprint(EPEAT GOLD) KB
54Y9431	1	NetVista Keyboard (USB)
54Y9434	1	NetVista Keyboard (USB)
54Y9438	1	NetVista Keyboard (USB)
54Y9404	1	NetVista Keyboard (USB)
54Y9519	1	Edge KB New F5 USB
54Y9425	1	NetVista Keyboard (USB)
54Y9460	1	NetVista Keyboard (PS2)
54Y9403	1	NetVista Keyboard (USB)
54Y9555	1	Fingerprint(EPEAT GOLD) KB
54Y9419	1	NetVista Keyboard (USB)
54Y9446	1	NetVista USB Nordic
KEYBOARD & MOUSE		
03X6222	1	FRU-KYB_MOUSE Arabic/French
03X6230	1	FRU-KYB_MOUSE Dutch
03X6249	1	FRU-KYB_MOUSE Spanish
03X6233	1	FRU-KYB_MOUSE French Canadian
03X6248	1	FRU-KYB_MOUSE Slovak
03X6245	1	FRU-KYB_MOUSE Polish
03X6227	1	FRU-KYB_MOUSE Chinese/US/Taiwanese
03X6231	1	FRU-KYB_MOUSE French
03X6228	1	FRU-KYB_MOUSE Czech (QWERTY or ABB)
03X6221	1	FRU-KYB_MOUSE Arabic
03X6232	1	FRU-KYB_MOUSE French Canadian
03X6223	1	FRU-KYB_MOUSE Belgium/French
03X6229	1	FRU-KYB_MOUSE Danish
03X6250	1	FRU-KYB_MOUSE Swedish/Finn
03X6226	1	FRU-KYB_MOUSE Bulgarian
03X6242	1	FRU-KYB_MOUSE Korean
03X6224	1	FRU-KYB_MOUSE Belgium/UK
03X6238	1	FRU-KYB_MOUSE Hungarian
03X6247	1	FRU-KYB_MOUSE Russian/Cy US
03X6244	1	FRU-KYB_MOUSE Norwegian
03X6246	1	FRU-KYB_MOUSE Portugese
03X6240	1	FRU-KYB_MOUSE Italy
03X6235	1	FRU-KYB_MOUSE Greek /Greece, Cyprus
03X6236	1	FRU-KYB_MOUSE Greek/US
03X6237	1	FRU-KYB_MOUSE Hebrew

03X6243	1	FRU-KYB_MOUSE LA Spanish
03X6239	1	FRU-KYB_MOUSE Iceland
03X6220	1	FRU-KYB_MOUSE US English
03X6225	1	FRU-KYB_MOUSE Brazil/Portuguese
03X6234	1	FRU-KYB_MOUSE German
LINECORDS		
42T5056	1	SA-1.0M
42T5029	1	Europe-1.0M
42T5017	1	Argentina-1.0M
42T5065	1	China-1.0M
42T5071	1	Taiwan-1.0M
42T5044	1	SWS-1.0M
42T5062	1	Israel-1.0M
42T5004	1	US/Canada-1.0M
42T5041	1	Denmark-1.0M
42T5035	1	UK-1.0M
42T5050	1	ANZ-1.0M
42T5083	1	India-1.0M
45N0437	1	Longwell 3pin Japan(type 2)
42T5174	1	Brazil-1.0M
42T5077	1	Korea-1.0M
42T5047	1	Italy-1.0M
45N0131	1	New release Luxshare 3pin CCC power cord -CHN